NOTICE

Your Odyssey Master Control Unit has been calibrated at our factory to the highest standards that will give you years of carefree operation.

Since all brands of television receivers do vary in their performance characteristics, you may find it necessary to adjust the Horizontal Hold control on your television in order to stabilize your Odyssey picture. A Horizontal Frequency control is provided on your Odyssey on the bottom of the Master Control Unit to allow you to adjust your Odyssey to be more compatible with your television receiver. Insert a thin blade screwdriver in the hole marked HORZ FREQ and turn the control until your Odyssey picture is stabilized. You will now be able to change between regular television viewing and Odyssey without making adjustments to your television receiver.

Printed in USA

EL3028-1